

RICOH

Extension Adapter TE-1



L87010

Made in Japan

■はじめに

このたびは、当社製品をお買い上げいただきありがとうございます。
でございます。

本製品は RICOH THETA S に USB や HDMI のコネクタ
および三脚を接続してご使用いただく場合、それらが干
渉しないようにするためのアダプタです。内容を良くご
理解の上、正しくご使用ください。

本製品は、RICOH THETA S 専用となります。

■RICOH THETA S への取り付け方

RICOH THETA S の底面にある三脚穴に、本製品のネジ
部をしっかりと取り付けてください。

取り付け、取り外しの際にはネジ穴に対して垂直にした
状態で、本製品を回転して取り付けてください。

過度の締め付けにより外しにくくなったり RICOH
THETA S に破損が生じる場合があります。取り付けの際
にご注意ください。

■使用上の注意

確実に取り付け使用してください。不完全な状態で使
用すると、カメラの落下等をおこす恐れがあります。

本製品を RICOH THETA S に装着した状態で振り回した
り、強く引っ張ったりしないでください。

本製品を RICOH THETA S および三脚等に取り付けた状
態で持ち運ぶ際には、三脚を持って運んでください。また、
三脚ごと転倒させないようにご注意ください。

■Before you begin:

Thank you for purchasing our product.

This adapter is designed to prevent interference
when both a connector, such as a USB or HDMI
cable, and a tripod are attached to your RICOH
THETA S at the same time.

It is only for use with the RICOH THETA S.

■How to attach to RICOH THETA S

Please screw the threaded portion of the adapter
firmly into the tripod hole on the base of the
RICOH THETA S.

When attaching or removing this adapter, turn the
entire adapter while holding it perpendicular to
the screw hole.

Take caution when attaching the adapter. If it is
attached too firmly the adapter may be difficult to

remove, and could cause damage to the RICOH
THETA S.

■Operating precautions

Attach securely. If the adapter is attached too
loosely there is a danger the camera could fall off.

Do not swing or yank this product around while
the RICOH THETA S is attached.

When carrying this product while attached to the
RICOH THETA S and tripod, always hold the tripod.
Additionally, take care to ensure that the tripod
and attached products do not tip over.